

Powertest 3P

BRAKENSIEK®
SYSTEMHAUS



Powertest 3P

Measuring instrument for electrical safety testing

VDE 0701/2 meter for direct connection up to 32A and 25kW with power calculation and display

DIN EN 61010-1 (VDE 0411 Part 1)

DIN VDE 0404 part 1 and part 2

61557-1/-4/-10 Din EN (VDE 413 Part 1, Part 4, Part 10)

Delivery:

Probe

Certificate

- Tests to BGV A3 (BGV A2)
 - For all specimens with Schuko, IEC connector, CEE 16A 1P, 16A and 32A 3CEE 3CEE connection
 - Check extension cords
 - Automatic test sequence, text handling and good / fault indication
 - Functional test with true RMS power meter
 - Check the network connection to the rotating field and PE connection. Automatic shutdown when dangerous fault current of the device under test.
 - Data storage in the base unit
 - Data input via keyboard, barcode reader or PC
 - Not required repositioning of the specimens
 - Temperature and current measurements Pliers
 - With integrated test management and expediting
- Retrieval ability of the due dates
- Remote control and display in probe

Features:

The tester POWER TEST 0701/0702 3P is used to test for repair and for re-examination of portable test equipment with a power up to 25kW. It contains all standard power outlets for AC and three-phase loads.

For convenient inspection of extension cords are attached to the connector sockets. The network connection is via a 32A CEE Dose. Connection cable for 16A CEE and shockproof are available. The instrument and accessories is located in a rugged protective case.

The POWER TEST 0701/0702 3P contains some measures to protect the Examiner:

- The 16A circuits in the device are covered separately.
- A built-in residual current monitor will turn the power off automatically when the test specimen dangerous fault currents (greater than 20 mA).
- A connection identifier detects the presence of the PE connector in the system and check the phase rotation of the feed.

The measurements are all integrated on a test lead wire compensation.

All according to DIN VDE 0701 and DIN VDE 0702 required measurements are possible:

Passive measurements (DUT is not powered up):

- Protective conductor resistance
- Insulation resistance
- Equivalent Leakage

Active measurements (device under test is supplied with power via a contactor):

- Protective conductor current (difference current method)

- Contact current
- Voltage, current and power measurement over the full rated power. Parallel to the performance measurement is a continuous differential current measurement.

As measurements are also possible:

- Temperature measurement via an adapter
- Clip-on current measurements

Operation is menu-driven via a backlit LCD display. In order to meet different user groups, user profiles are the "professional" and "Beginner" set. Before the test, a classification of the test is to define the test procedure and the setting of limits on the chosen VDE regulations. (Eg, protection class, heating, ground wire length). Test sequences for lines and fixed installations are also available.

The measured values are automatically stored in the device and can then read by the PC and a convenient database and logging software (option), printed and archived. The distinction of the samples via an identification number input via the keyboard or a barcode reader can be connected to the interface.



Please only contact us via our registration form and only if you are a business person yourself. Every offer is subject to prior sale and includes your acceptance to our terms & conditions [Terms and conditions \(AGB\)](#). All logos and trademarks on this site are the property of their respective owners.

You will always receive an invoice including tax, which can be paid via wire transfer, in advance or cash. If you register on paypal, you may also pay by charging your paypal account with your credit card. If you are an EU member and you have a validated tax number which can be validated here: [VIES VAT number validation / MwSt.-Informationsaustauschsystem MIAS\) Validierung der MWSt.-Nummer](#) then you pay tax-free. If you are from outside the EU, you can only pay tax-free, if the export is done with the transport company, called 'Schenker'. If you are not using 'Schenker', we cannot guarantee that we will get the export confirmation in time. In that case, you have to pay tax and you get it.

Mitglied der

**Brakensiek Systemhaus
GmbH & Co. KG
Klönnestraße 94
D-44143 Dortmund****BRAKENSIEK®**
SYSTEMHAUS

Mitglied im

**www.brakensiek.com****Tim Brakensiek**

Mitglied des

 **+49(0)231.985-00 10**

Premium Partner

 **+49(0)231.985-2000**