

Ersatzteile Tango 1



Spare parts for Heidelberg / Linotype-Hell Tango 1

Parts List

00009809

Washer - DIN 988 DI 6

00044881

Screw - M3x8 DIN 912

00044903

Screw - M3x10 DIN 912

00044938

Screw - M4x10 DIN 912

00044946 Screw - DIN 912 M4x12

00045039

Screw - M6x16 DIN 912

00045349

Set screw - M3x6 DIN 916

00045438

Set screw - M6x8 DIN 916

00045500

Screw - M4x10 DIN 921

00045608

Screw - M4x4 DIN 923

00049158

Screw - M4x8 DIN 912

00049638

6kt-mother - M3 DINEN 24 032

00049719

6kt nut - DIN 985 M4

00050644

Male - 28 752 2x8 DINEN

00051004

Deep groove ball bearings - DI 3

00051438

Deep groove ball bearings - DI 8

00054151

Washer - DI 4 DIN 6799

00055255

Disc - DI 4.3 DIN 125

00055301

Disc - 4.3 DI DIN 9021

00058130

Washer - DI 7 DIN 6799

00079936

Screw - M3x12 DIN 912

00090077

Disc - 3.2 DI

00094358

Bumpon

00094617

Gripping ring

00094684

Bumpon

00127159

Cable clamp

00127337

Cable Ties

00127787

Cable Ties

00131865

Screw - M6x6 DIN 923

00146455

Washer - DI 10 DIN 6799

00146552

6kt-mother - M4 DINEN 24 032

00156566

Screw - M4x16 DIN 912

00160202

Screw - M4x6 DIN 912

00164828

Circlip

00164909

Screw - M4x20 DIN 912

00166189

Screw - M2, 5x5 DINEN 7046

00166421
Locking washer - DI 6.1

00175153
Washer - DIN 433 3.2 DI

00206849
Set screw - M4x6 DIN 916

00207047
Screw - M3x6 DIN 912

00207098
Screw - M4x40 DIN 912

00207381
Screw - M4x25 DIN 912

00207527
Screw - M6x25 DIN 912

00207616
Screw - M4x45 DIN 912

00210218
Screw - M4x8 DIN 923

00215139
Screw - M3x5 DIN 912

00216267
Screw - M4x2, 5 DIN 923

00218146
Screw - St2, 2x4, 5 DIN 7981

00219991
Locking washer - DI 4.1

00221791
Disc - 2.7 DI DIN 9021

00231657
Disc - 6.4 DI

00232882
Disc - 8.1 DI

00233943
Washer - DI 8 DIN 6799

00233951
Washer - DI 9 DIN 6799

00234028

Snap ring

00284831

Deep groove ball bearings - DI 8

00310786

Lens - F = 12.76 mm

00359076

Screw - M8x60 DINEN 24 017

00415952

Screw - M2x10 DINEN 1207

00441996

Belleville spring

00492302

Set screw - M4x12 DIN 916

00510831

Bearings - DI 12

00971073

O-ring

00991015

Disc - 6.1 DI

01045903

Deep groove ball bearings - DI 4

01181041

Disc - 8.1 DI

01184598

Disc - DI 12

01212680

Screw - M3x8

01423908

Screw - M3x6

01424238

Screw - St2, 9x13 DIN 7981

01487272

Screw - M4x10 DINEN 7045

01487396

Screw - M3x6 DINEN 7046

01487477

Screw - M3x16 DINEN 7045

01487485

Screw - M3x8 DINEN 7046

01487531

Screw - M3x10 DINEN 7045

01487736

Screw - M4x8 DINEN 7045

01586289

Screw - M4x12

01756796

O-ring

01992023

Cuff

02079836

Screw - M3x8 DINEN 7045

02080443

Screw - M2, 5x6 DINEN 7045

02133113

Flex-Loc-element

02255391

Coupling two

02288303

Disc - 2.2 DI DIN 6796

02288370

Disc - 3.2 DI DIN 6796

02288389

Disc - 4.3 DI DIN 6796

02288400

Disc - 6.4 DI DIN 6796

02441748

Photo-Multiplier

02445786

Coupling (ET group)

02456982

Tension

02546272

Compression spring

02586053
Disc - 4.3 DI

02777150
Halogen lamp

02944901
Stopper

02949075
Disc - DI 4

04076249
Washer - DIN 988 DI 3

04187776
Pull magnet

04189000
Microswitch

04213378
Compression spring

04242963
Screw - M3x5 DINEN 7045

04277996
Plate

04593243
Signal filtering

04670833
Mother Bar

04686063
Screw - 3x12

04703324
Rubber plate

04716876
Screw - M3x10 DINEN 7046

04772903
Washer - DIN 988 DI 6

04791355
Fan

04797922
Mother

04853342
Wheel

04901096
Spindle

04901118
Engine Mount

04901126
Bush

04901207
Feeder

04923898
Bearings - DI 3

04924584
Microswitch

04958780
Light barrier 1

04958802
Light barrier 2

04972724
IR cut filter

04972945
MP-BOARD-T4 - 6149

04972953
Logarithmic - 6159

04974786
T4-AD-CONVERTER - 6160

04979168
Scanning-T4 - 6156

04983483
HIGH VOLTAGE-T4 - 6172

04983521
Rope

04984048
Cover

04984064
Cover, rear (without caps)

04984196

Leg 1

04984226

Axis

04984285

Panel, left

04984366

Stepper motor

04984382

Fan tray

04984390

Side panel, left

04984404

Side panel, right

04984978

PANEL-T4 - 6164

04984994

Aperture

04985532

Hood 1

04985540

Hood 2

04985893

Power Supply - 24V

04986008

Filter

04986040

Aperture / filter group

04986091

Beamsplitter

04986199

Mirror

04986253

Mirror Group

04986261

Block

04986407

Timing

04986636

Magnet for cover

04986644

Objective Plate

04986660

Stopper

04986687

Diaphragm lever

04986725

Cover plate

04987128

Cover

04987152

Motor drive

04987160

Attack angle

04987349

Cover

04987381

Fiber optic - transmission

04987411

Fiber optics - reflection

04987586

Insulation

04987624

Lower part

04987632

Cover 1

04987764

Actuator

04988876

BOARD MAXI-T4 - 6157

04990056

Seal

04990226

Plug housing

04991699
Leaf spring

04993241
Cap

04999096
Sheet

05000009
Fork

05003873
Stepper motor - 12V

05004209
Screw - M14x1, 5

05008344
Inverter - 230V 50/60 Hz

05011981
Contactor relay - 24V 10A

05013682
Bush

05013690
Pulley

05013712
Bolt

05014298
Role

05014859
Timing

05014875
Screw - 5x12

05015545
Motor with gear

05016657
Pulley with bearing

05016665
Axis

05109329
Perforated plate

05111757

Pulsor, cpl.

05123151
Cover

05123771
Clip

05123917
Clip

05124212
Cover

05125200
ENTSTOER_MOT - 6186

05125588
Stepper motor

05126061
Spring

05126428
Plate

05127025
Flap

05127750
Key 1

05128250
Cover assy.

05128382
6kt nut - M14x1, 5 28 675 DINEN

05128803
Keyboard Cover

05129206
Compression spring

05129362
Cap

05129435
Key 2

05130840
Head group

05131529
Diaarm

05131723
Screw - 5x14

05132517
Cover

05134293
Rotary encoder with grid plate

05134862
Disc - DI 4

05134870
Collar

05135575
Cover

05135710
Screw - M4x12 DIN 912

05135729
Interim Management

05135826
Rear wall

05136318
Spring strap

05136342
Foot

05139651
AD BA T4 - 6193

05141796
Shielding

05141893
Hood

05142504
Torsional

05145562
Seal

05150612
Weight

05150914
Freewheel

05154170
Reflector

05154758
Plate

05157137
Bulkhead

05157897
Holder AL

05157978
Holder DL

05162149
Insulating

05162769
Lighting

05165059
Screw - M8x65 DINEN 24 017

05167701
Cover

05173957
Hood, complete.

05180457
Duct

05181461
Slide-mounted device

05185785
Cover

05190126
Partition

05190193
Insulation

05193575
Axis

05193982
Bolt

05194008
Plate

05194113

Photoprotective

05196957
Bearing nut

05196965
Support column

05197058
Catches

05197074
Button

05197163
Sidewall, the right

05197171
Sidewall, the left

05214815
I rubber roll, complete.

05214823
Rubber Roller II, complete.

05198046
Main drive (without rotary encoder)

05204364
Role

05205115
Shroud

05205476
Role

05205484
Axis

05205506
Ring

05205611
Roll holder, bottom

05205654
Driver

05205662
Dental unit

05206049
Disc - DI 12

05206103
Roll Holder, above

05209048
Deflector

05209544
Switching unit

05209749
Bush

05217318
Deep groove ball bearings - DI 8

05217326
Screw - M4x16 DIN 912

05217644
Objective Plate

05220319
Compression spring

05220920
Copydot - 6248

05221455
Angle above

05222052
Angle, below

05222117
Leg spring

05222125
Roll Holder, above

05222176
Holder

05222222
Bush

05222311
Roll holder, bottom

05222354
Holder

05223865
Cover

05223881

Key

05224012

BOARD MAXI-T4-COP - 6256

05228379

Plate

05228387

Angle

05238897

Beamsplitter

05240433

Pin I

05240441

Pin II

05240468

Role I

05240476

Part II

05240867

Set of rollers / pins

05240913

Gas spring

05241898

Bush

05243599

Angle

05243602

Plate

05246369

Driver

05251400

Hood

05251516

HIGH-VOLTAGE-T4A - 6266

05251583

Roller carriage

05253586

Hook

05262615

Role - with ball bearings

05264022

Readhead T4 GW - 6270

05271495

Photo-Multiplier

05297966

Button to complete.

05369800

Connector sleeve

05372356

Pulley with bearing

05375193

Plug housing

05135818

Caps (2 pcs., Left and right)

05328810

Adapter BA X15 - X19

05522439

BOARD MAXI TANGO

05244765

Mother holder (without shock)

05171822

Damper

05159040

Jack (incident)

05159814

Socket (transmitted light)

BRAKENSIEK®

SYSTEMHAUS

No picture available.

Please only contact us via our registration form and only if you are a business person yourself. Every offer is subject to prior sale and includes your acceptance to our terms & conditions [Terms and conditions \(AGB\)](#). All logos and trademarks on this site are the property of their respective owners.

You will always receive an invoice including tax, which can be paid via wire transfer, in advance or cash. If you register on paypal, you may also pay by charging your paypal account with your credit card. If you are an EU member and you have a validated tax number which can be validated here: [VIES VAT number validation / MwSt.-Informationsaustauschsystem MIAS\) Validierung der MWSt.-Nummer](#) then you pay tax-free. If you are from outside the EU, you can only pay tax-free, if the export is done with the transport company, called 'Schenker'. If you are not using 'Schenker', we cannot guarantee that we will get the export confirmation in time. In that case, you have to pay tax and you get it.

Mitglied der

**Brakensiek Systemhaus
GmbH & Co. KG
Klönnestraße 94
D-44143 Dortmund****BRAKENSIEK®**
SYSTEMHAUS

Mitglied im

**www.brakensiek.com****Tim Brakensiek**

Mitglied des

 **+49(0)231.985-00 10**

Premium Partner

 **+49(0)231.985-2000**