

Handbuch Linotype-Hell ChromaGraph S 3900



Manual Linotype-Hell ChromaGraph S 3900

Non-new

Pages: 75

Size: 21 cm x 23 cm

Language: German

Colour: no

Revision:

Ident / Partnr. 04748093

Structure:

Device and function description

Commissioning

Operating and display elements

Operation

Maintenance and Care

Specifications

Appendix / Stichwortverzeichnis

Contents A to Z:

Abtastanfang

Circumferential direction, 4-17

Feed direction, 4-1 7

Scan geometry, 4-1 7

Scanning light switch. 4-12

Scanning spot, 3-4

Scanning roller

check for scratches, 5-5

Hook. 4-4

. remove 4-4

Abtastwalzenbremse, 3-9

Abtastwalzenwechsel, 4-3

Connection of data cables, 2-4

Supervision, 4-14, 4-15

Aufstclln of the device, 2-3

Off, 2-8

Austaiisch the air filter, 5-6

Bar-code label. 4-4

Scanning panel, 3-4

Viewing optics. 4-8

Picture. 4-19

Picture lamp

to exchange 5-8. 5-10

to adjust 5-8, 5-10

Disk, 1-8

Diabetrachtungslampe exchange. 5-13

Perusal. 4-14,4-15

Eichort. 4-15

Eichort set, 4-15, 4-16

Switch, 2-6

Focus release, 4-8

Focus ring, 3-8, 4-13

In EMI. 6-6

Generate end. 4-1 9

Basic setup, 4-14
Attitude. 4-12
Generate job. 4-10
Secure job. 4-19
Job creation. 4-10
Folding Lens, 4-8, 4-13
Folding swivel lens, 3-5
Folding mirror swivel, 3-5
Clear glass. 4-14
Power switch, 2-4, 2-8. 3-3
Power supply. 3-3
Newton rings. 4-6
Norms and standards, 6-5
White Paper, 4-14
Periodic maintenance, 5-4
Sampling. 3-4
Ileferenzweiß, 4-1 5
Clean
the scanning roller, 5-7
the sliding surfaces, 5-5
the air filter, 5-6
the optics, 5-5
Schadstome, 6-6
Scharieeinstellung Ablastkopf. 3-8, 4-8,
4-12
Security
electric. 6-5
mechanical. 6-5
Safety. 5-3
Signal lamps. 3-7
Software installation, 2-5
Standard track. 4-14
Starting position sensor roller, 3-4
Starting point to measure. 4-18
Starting point setting. 4-17
Abtastanfang
Circumferential direction, 4-17
Feed direction, 4-1 7
Scan geometry, 4-1 7
Scanning light switch. 4-12
Scanning spot, 3-4
Scanning roller
check for scratches, 5-5
Hook. 4-4
. remove 4-4
Abtastwalzenbremse, 3-9
Abtastwalzenwechsel, 4-3
Connection of data cables, 2-4
Supervision, 4-14, 4-15
Aufstcllc n of the device, 2-3
Off, 2-8
Austaiisch the air filter, 5-6
Bar-code label. 4-4
Scanning panel, 3-4
Viewing optics. 4-8

Picture. 4-19
Picture lamp
to exchange 5-8, 5-10
to adjust 5-8, 5-10
Disk, 1-8
Diabetrachtungslampe exchange. 5-13
Perusal. 4-14, 4-15
Eichort. 4-15
Eichort set, 4-15, 4-16
Switch, 2-6
Focus release, 4-8
Focus ring, 3-8, 4-13
In EMI. 6-6
Generate end. 4-1 9
Basic setup, 4-14
Attitude. 4-12
Generate job. 4-10
Secure job. 4-19
Job creation. 4-10
Folding Lens, 4-8, 4-13
Folding swivel lens, 3-5
Folding mirror swivel, 3-5
Clear glass. 4-14
Power switch, 2-4, 2-8. 3-3
Power supply. 3-3
Newton rings. 4-6
Norms and standards, 6-5
White Paper, 4-14
Periodic maintenance, 5-4
Sampling. 3-4
Lieferenzweiß, 4-1 5
Clean
the scanning roller, 5-7
the sliding surfaces, 5-5
the air filter, 5-6
the optics, 5-5
Schadstoffe, 6-6
Scharfeinstellung Abblastkopf. 3-8, 4-8,
4-12
Security
electric. 6-5
mechanical. 6-5
Safety. 5-3
Signal lamps. 3-7
Software installation, 2-5
Standard track. 4-14
Starting position sensor roller, 3-4
Starting point to measure. 4-18
Starting point setting. 4-17



Please only contact us via our registration form and only if you are a business person yourself. Every offer is subject to prior sale and includes your acceptance to our terms & conditions [Terms and conditions \(AGB\)](#). All logos and trademarks on this site are the property of their respective owners.

You will always receive an invoice including tax, which can be paid via wire transfer, in advance or cash. If you register on paypal, you may also pay by charging your paypal account with your credit card. If you are an EU member and you have a validated tax number which can be validated here: [VIES VAT number validation / MwSt.-Informationsaustauschsystem MIAS\) Validierung der MWSt.-Nummer](#) then you pay tax-free. If you are from outside the EU, you can only pay tax-free, if the export is done with the transport company, called 'Schenker'. If you are not using 'Schenker', we cannot guarantee that we will get the export confirmation in time. In that case, you have to pay tax and you get it.

Mitglied der

**Brakensiek Systemhaus
GmbH & Co. KG**
Klönnestraße 94
D-44143 Dortmund**BRAKENSIEK®**

SYSTEMHAUS

Mitglied im

**www.brakensiek.com****Tim Brakensiek**

Mitglied des

 **+49(0)231.985-00 10**

Premium Partner

 **+49(0)231.985-2000**